ASSEMBLY INSTRUCTIONS

MODEL: WM1700A-ET2

IMPORTANT NOTE:

- * PLACE ALL WOODEN PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A RUG OR CARPET TO AVOID THE PARTS FROM BEING SCRATCHED.
- * BEFORE YOU BEGIN, KINDLY FOLLOW THE ASSEMBLY INSTRUCTIONS STEP BY STEP.

HARDWARE LIST			
Α	JCBC M6 x 70mm + S/W M6 + F/W M6 x 13mm	8PCS	
В	ALLEN KEY M4	1PC	
С	PH C/B SCREW #8 x 32mm <ttttt(x)< th=""><th>4PCS</th></ttttt(x)<>	4PCS	

PART LIST			
1	END TABLE TOP	1PC	
2	END TABLE LEG	4PCS	



COMPLETED END TABLE ASSEMBLY.

STEP 1



